

Boistfort Management Unit

Boistfort Management Unit – Stillman Creek

Major Tributaries:

Lost Creek
Halfway Creek
Keller Creek
Little Mill Creek

Anadromous Fish Stocks:

Fall Chinook
Spring Chinook
coho
cutthroat trout
winter steelhead

Tier 1 Concerns

Water quality, Fish Passage, Sediment

- Abandon roads on steep geologically sensitive areas
- Correct barrier culverts
- Identify specific degraded riparian areas for restoration needs
- Implement TMDL actions
- Install riparian fencing to exclude or reduce livestock access
- Interplant conifers in deciduous dominant areas where appropriate
- Reduce sediment loading by reducing road densities (abandon/decommission)
- Revegetate open areas with native plants
- Upgrade logging roads to comply with Forest Practices Act Rules and Regulations

Tier 2 Concerns

Large woody Debris, Riparian, Water Quantity, Floodplain

- Abandon roads on steep geologically sensitive areas
- Control invasive species
- Correct cross drains that may trigger mass wasting on geologically sensitive slopes
- Develop LWD supplementation plan that will install logjams and key pieces
- Educate landowners on the importance of leaving LWD in the stream
- Identify sources that are contributing to sediment loading
- Identify specific degraded riparian areas for restoration needs
- Implement alternative methods of bank stabilization (bioengineering) in locations of excessive erosion
- Install LWD pieces in conjunction with other restoration projects
- Install riparian fencing to exclude or reduce livestock access
- Interplant conifers in deciduous dominant areas where appropriate
- Protect key properties of riparian habitat by a fee simple or easement
- Reconnect, enhance, and/or restore potential off channel floodplain and wetland habitat
- Reduce sediment loading by reducing road densities
- Revegetate open riparian areas with native plants
- Revegetate stream and riverbanks for at a protection from erosion
- Upgrade logging roads to comply with Forest Practices Act Rules and Regulations

Tier 3 Concerns

Water Quantity, Floodplain

- Abandon roads on steep geologically sensitive areas
- Correct cross drains that may trigger mass wasting on geologically sensitive slopes
- Develop LWD supplementation plan that will install logjams and key pieces
- Identify sources that are contributing to sediment loading
- Implement alternative methods of bank stabilization (bioengineering) in locations of excessive erosion
- Install LWD pieces in conjunction with other restoration projects
- Reconnect, enhance, and/or restore potential off channel floodplain and wetland habitat
- Reduce sediment loading by reducing road densities
- Revegetate stream and riverbanks for at a protection from erosion
- Upgrade logging roads to comply with Forest Practices Act Rules and Regulations

